

EKON wheelbearings, - kits

part number system



EKON part numbers are 10-digit part numbers, divided in 3 blocks

example;

112 57009 15

the first 3 digits define the product:

111 wheelbearingkit	with tapered roller bearing
112 wheelbearingkit	with ball bearing
123 wheelbearingkit/wheelhubkit	with wheelhub
124 wheelbearingkit/wheelhubkit	with wheelhub and ABS
101 wheelbearing	tapered roller bearing
102 wheelbearing	ball bearing
133 wheelhub	hub unit (with bearing)
134 wheelhub	hub unit (with bearing) and ABS

Digit 4 and 5 define the car maker
digit 6 to 8 are numerous

57...	Audi
58...	Fiat
53...	Opel etc

Digit 9 and 10 show details like

10	front
15	front / rear
20	rear

result:

112 57009 15

is a wheelbearingkit with ball bearing for Audi,
which can be fitted in the front or rear.